

- 1. LADDER AND PLATFORM SHIP LOOSE. FIELD INSTALLATION BY OTHERS IS REQUIRED.
- 2. THE BOTTOM OF THE LADDER DOES NOT EXTEND PAST THE BASE OF THE UNIT. IF THE UNIT IS ELEVATED THEN AN OPTIONAL EXTENDED LADDER PACKAGE SHOULD BE CONSIDERED. (CONSULT FACTORY)
- 3. REFER TO RIGGING PACK FOR LADDER AND PLATFORM MOUNTING INSTRUCTIONS.
- 4. EACH PLATFORM AND LADDER ASSY. WEIGHS 560 LBS.
- 5. FOR STANDARD UNITS, REFER TO UNIT CERTIFIED PRINT FOR PUMP LOCATION(S).